

Installation of Cat 5 Hurricane Screens

1. Verify Number of openings to be covered (proper # of panels to proper number of openings).
2. Standard CAT5 install is done from bottom up. Windows are outside mount and can be done top to bottom.
3. Re-roll screen if needed, to allow bottom bar to be up.
4. Measure 2" off edge of wall, column or other building material. Use chalk line to snap a guideline for bottom bar.
5. Make sure screen panel is even on each side or centered properly on a trapped opening.
6. Starting from one side, temporarily attach screen to floor with tapcons in every other pre-drilled hole. Mark all other holes.
7. Once bottom is done, you may now unroll and stretch screen panel to its full height (panel should be pulled tight and use speed square for leverage).
8. Drill and mount top bar with tapcons and studded panel mates (panel mates are needed to hold hood in place). The panel mates are pre-marked on the bar to match up with grommets in the hood.
9. If your CAT 5 screen is removable, all top holes will require panel mates.
10. Drill out all holes for panel mates, remove tapcons and install panel mates.
11. While panel is up, you should match tabs or grommets on the side of each screen if necessary.
12. Now remove tapcons from floor and roll screen tightly and hang in hood.
13. Drill out holes in floor and walls, vacuum out all dust from holes.
14. Install leads and sidewalk bolts, wood wall will require panel mates or brass anchors.