

Measurement Instructions

Window Mount:

For mount without hood – top to bottom, side to side

- Add 8" to height and width (example: buck measurement 36 x 36= finished 44 x 44)
- Make sure there is 4" clearance on each side- no obstructions on top and bottom.
- If horizontal mount- make sure no obstructions on either side. If any obstructions, product can be notched to accommodate.

For Mount with Hood—top to bottom only (if removable, for storage purposes we can make a storage bag).

- Add 14" to height (example: buck measurement 36 x 36= finished 50 x 44)
- Make sure there is a 4" clearance on each side-no obstruction on top or bottom

For Mounting to Floor: (lanai, entryway, porches, and garage)

For mount without hood – top to wall, bottom to floor

- Add 8" to width
- Add 5 ½" to height- the bottom bar makes its own angle.

For mount with hood-

- Add 11" to 13" to height (to accommodate the hood)
- Add 8" to width (unless trap opening)
- Hood measurement is same as width.